Autonics TCD210055AC

Universal AC/DC Photoelectric Sensors



BEN Series

PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Features

- · Small and power supply built-in type
- · Easy installation with indicators on product
- Light ON/Dark ON mode selectable by switch
- Status and output indication
- Built-in IC photo diode for disturbing light and electrical noise

Safety Considerations

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

⚠ Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g., nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) ailure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.

Failure to follow this instruction may result in explosion or fire.

- **03. Do not disassemble or modify the unit.**Failure to follow this instruction may result in electric shock or fire.
- 04. Do not connect, repair, or inspect the unit while connected to a power source.

Failure to follow this instruction may result in electric shock or fire.

05. Check 'Connections' before wiring.

Failure to follow this instruction may result in fire.

⚠ Caution Failure to follow instructions may result in injury or product damage.

01. Use the unit within the rated specifications.

Failure to follow this instruction may result in fire or product damage

- 02. Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in electric shock or fire
- 03. Do not use a load over the range of rated relay specification. Failure to follow this instruction may result in insulation failure, contact melt, contact failure, relay broken, or fire

Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, It may cause unexpected
- \bullet When connecting an inductive load such as DC relay or solenoid valve to the output, remove surge by using diodes or varistors.

 • Use the product after 0.5 sec of the power input.
- When using a separate power supply for the sensor and load, supply power to the
- The power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Wire as short as possible and keep it away from high voltage lines or power lines to prevent surge and inductive noise.
- When using switching mode power supply (SMPS), ground F.G. terminal and connect a condenser between 0V and F.G. terminal to remove noise.
- When using a sensor with a noise-generating equipment (e.g., switching regulator, inverter, and servo motor), ground F.G. terminal of the equipment.
- This unit may be used in the following environments.
 Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2.000 m
- Pollution degree 2
- Installation category II

Product Components

| Sensing type | Through-beam | Retroreflective | Polarized retroreflective | Diffuse reflective |
|------------------------|-------------------|-----------------|---------------------------|--------------------|
| Product components | Product, instruct | ion manual | | |
| Reflector | - | MS-2 | MS-2 | - |
| Adjustment screwdriver | ×1 | ×1 | ×1 | ×1 |
| Bracket | × 2 | ×1 | ×1 | ×1 |
| M4 bolt / nut | × 4 | × 2 | × 2 | × 2 |

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

BEN 0 8

Sensing distance

Number: Sensing distance (unit: mm) Number+M: Sensing distance (unit: m)

Sensing type T: Through-beam

M: Retroreflective

P: Polarized retroreflective

D: Diffuse reflective

Sold Separately

· Reflector: MS Series

• Retroreflective tape: MST Series


Output method

FR: AC/DC power, relay conctact output

DT: DC power, solid state (transistor) output

Cautions during Installation

- Be sure to install this product by following the usage environment, location, and specified ratings. Consider the listed conditions below.
- Installation environment and background (reflected light)
- Sensing distance and sensing target
- Direction of target's movement
- Characteristic curves
- · When installing multiple sensors closely, it may result in malfunction due to mutual interference.
- Retroreflective: If the sensing target has a glossy surface or high reflection, tilt the sensing target with an angle from 30 to 45 degrees and install the sensor.



- \bullet For installation, tighten the screw with a torque of 1.2 N m. Mount the brackets correctly to prevent the twisting of the sensor's optical axis.
- Do not impact with a hard object or bend the cable excessively. That could decrease the product's water resistance.
- Use this product after the test. Check whether the indicator works appropriately for the positions of the detectable object.

| Through-beam | Retroreflective | Reflective |
|---|---|---|
| | | |
| Emitter - Receiver: Install to face each other | Sensor - Reflector: At least 0.1 m apart, install to face each other (parallel with the sensing side of the unit) | Sensor - Sensing target: Install to face each other (parallel with the sensing side of the unit) |


Setting Operation Mode

- Be sure to set the mode before power-on.
- Use the offered adjustment screwdriver. Do NOT turn with excessive force to prevent product damage.

| L: Light ON mode | D: Dark ON mode |
|------------------|-----------------|
| | DO L |

Operation Timing Chart and Indicators

■ Light ON mode




· In Dark ON mode, the waveforms are reversed


Connections

■ AC/DC power, relay conctact output

Emitter


· Receiver, Retroreflective, Polarized retroreflective, Diffuse reflective type






■ DC power, solid state (transistor) output


· Receiver, Retroreflective, polarized retroreflective, Diffuse reflective type







Circuit

■ AC/DC power, relay contact output







- $OCP (over current protection), SCP (short circuit protection)\\ If short-circuit the control output terminal or supply current over the rated specification, normal control signal is not output due to the protection circuit.$


Sensitivity Adjustment

- Set the adjuster for stable Light ON area, minimizing the effect of the installation environment.
- Use the offered adjustment screwdriver. Do NOT turn with excessive force to prevent product damage.
- · The steps below are based on Light ON mode.

| STEP | Status | Description | |
|------|-------------|-------------|--|
| 01 | Received | MIN MAX | Turn the adjuster from MIN to MAX sensitivity and check the position (A) where the operation indicator activates under the light ON area. |
| 02 | Interrupted | MIN B MAX | Turn the adjuster from (A) to MAX and check the position (B) where the operation indicator activates under the light OFF area. If the operation indicator does NOT activate at the MAX (maximum sensitivity): MAX = (B). |
| 03 | - | MIN B MAX | Set the adjuster at the mid position between (A) and (B) for optimal sensitivity. |


Dimensions

• Unit: mm, For the detailed drawings, follow the Autonics website.




| A | Optical axis | C | Stability indicator (green) |
|---|---------------------------|---|-----------------------------|
| В | Operation indicator (red) | D | Power indicator (red) |

■ Reflector (MS-2)



■ Bracket



Specifications

| Model | BEN10M-T | BEN5M-M | BEN3M-P | BEN300-D | | |
|------------------------------|---|--|---------------------------|-------------------------------------|--|--|
| Sensing type | Through-beam | Retroreflective | Polarized retroreflective | Diffuse reflective | | |
| Sensing distance | 10 m | 0.1 to 5 m ⁰¹⁾ | 0.1 to 3 m ⁰¹⁾ | 300 mm ⁰²⁾ | | |
| Sensing target | Opaque materials | Opaque materials | Opaque materials | Opaque, translucent materials | | |
| Min. sensing target | ≥ Ø 16 mm | ≥ Ø 60 mm | ≥ Ø 60 mm | - | | |
| Hysteresis | - | - | - | ≤ 20 % of sensing distance | | |
| Response time | AC/DC power, relay contace output model: \leq 20 ms DC power, solid state (transistor) output model: \leq 1 ms | | | | | |
| Light source | Infrared | Infrared | Red | Infrared | | |
| Peak emission wavelength | 850 nm | 940 nm | 660 nm | 940 nm | | |
| Sensitivity adjustment | - | YES (Adjuster) | YES (Adjuster) | YES (Adjuster) | | |
| Operation mode | Light ON mode - D | Light ON mode - Dark ON mode selectable (Adjuster) | | | | |
| Indicator | Operation indicator (red), stability indicator (green), power indicator (red) (33) | | | | | |
| Approval | C€ FR ENI | | | | | |
| Unit weight (AC/DC power) | ≈ 354 g | ≈ 208 g | ≈ 208 g | ≈ 195 g | | |
| Unit weight (DC power) | ≈ 342 g | ≈ 200 g | ≈ 200 g | ≈ 187 g | | |

- Non-glossy white paper 100 × 100 mm
 Only for the emitter


| Output method | AC/DC power, relay conctact output | DC power, solid state (transistor) output | | | |
|--------------------------------|---|---|--|--|--|
| Power supply | $24\text{-}240\text{VAC} \sim \pm 10\%50/60\text{Hz}$ $24\text{-}240\text{VDC} = \pm 10\%$ (ripple P-P: $\leq 10\%$) | $12-24\text{VDC} = \pm 10\%$ (ripple P-P: $\leq 10\%$) | | | |
| Power / current consumption | ≤ 4 VA | It depends on the sensing type | | | |
| Through-beam | - | Emitter: ≤ 50 mA, receiver: ≤ 50 mA | | | |
| Reflective | - | - ≤ 50 mA | | | |
| Control output | Relay contact output | NPN open collector - PNP open collector simultaneous output | | | |
| Contact capacity | 250 VAC ~ 3 A of resistance load, 30 VDC== 3 A of resistance load | | | | |
| Conctact composition | 1c | - | | | |
| Relay life cycle | Mechanical: ≥ 50,000,000 Electrical: ≥ 100,000 | | | | |
| Load voltage | | ≤ 30 VDC== | | | |
| Load current |] - | ≤ 200 mA | | | |
| Residual voltage | | NPN: ≤ 1 VDC==, PNP: ≤ 2.5 VDC== | | | |
| Protection circuit | Reverse power protection circuit, output short overcurrent protection circuit | | | | |
| Insulation resistance | ≥ 20 MΩ (500 VDC megger) | | | | |
| Insulation type | Double or strong insulation (dielectric voltage between the measured input and the power: 1 kV) | | | | |
| Noise immunity | \pm 1,000 VDC— the square wave noise (pulse width: 1 μ s) by the noise simulator | ±240 VDC the square wave noise (pulse width: 1 μs) by the noise simulator | | | |
| Dielectric strength | Between the charging part and the case | e: 1,000 VAC ~ 50/60 Hz for 1 min | | | |
| Vibration | 1.5 mm double amplitude at frequency of 10 to 55 Hz in each X, Y, Z direction for 2 hours | | | | |
| Vibration (malfunction) | 1.5 mm double amplitude at frequency of 10 to 55 Hz in each X, Y, Z direction for 10 min | - | | | |
| Shock | 500 m/s² (≈ 50 G) in each X, Y, Z direction | on for 3 times | | | |
| Shock (malfunction) | 100 m/s² (≈ 10 G) in each X, Y, Z direction for 3 times | | | | |
| Ambient illuminance (receiver) | Sunlight: ≤ 11,000 lx, incandescent lamp: ≤ 3,000 lx | | | | |
| Ambient temperature | -20 to 65 °C, storage: -20 to 70 °C (no freezing or condensation) | | | | |
| Ambient humidity | 35 to 85 %RH, storage: 35 to 85 %RH (no freezing or condensation) | | | | |
| Protection rating | IP50 (IEC standard) | | | | |
| Connection | Cable type | | | | |
| Cable spec. | Ø 5 mm, Emitter: 2-wire, AC/DC power: | | | | |
| Wire spec. | | AWG22 (0.08 mm, 60-core), insulator outer diameter: Ø 1.25 mm | | | |
| Material | Case and case cover: heat resistant ABS retroreflective: PMMA) | Case and case cover: heat resistant ABS, sensing part: PC (polarized | | | |

Sold Separately: Reflector MS Series

| Appearance | Size (W × H) | Reflectance | Sensing type | Model |
|------------|----------------|----------------------|---------------------------|-------|
| 2000 | | Typical reflectivity | Retroreflective | MS-2 |
| | 40.5 × 60.5 mm | Typical reflectivity | Polarized retroreflective | MS-2A |
| | | High reflectivity | Polarized retroreflective | MS-2S |
| | | | Retroreflective | MS-3 |
| | 81.5 × 60.5 mm | High reflectivity | Polarized retroreflective | MS-3S |
| | 29.3 × 38 mm | Typical reflectivity | Retroreflective | MS-4 |
| | 15.4 × 24 mm | Typical reflectivity | Retroreflective | MS-5 |
| | 13.7 × 23 mm | Typical reflectivity | Retroreflective | MS-6 |

- Material: PMMA / ABS (front part / rear part)
- Installation: Bolt mounting

■ Dimensions



■ Cautions during Installation

- Select a reflector size that is suitable for the installation space and operating environment of the sensors.
- In general, a bigger size of the reflector results in a longer sensing distance.
- Reflectors with high reflectivity increase the sensing distance compared to typical
- The reflectance may vary depending on the operating environment for the sensors.

Sold Separately: Retroreflective Tape MST Series

| Appearance | Size (W × H) | Approval | Packaged unit | Sensing type | Model |
|------------|--------------|----------|---------------|---|-----------|
| | 50 × 50 mm | EAC | 10 | Retroreflective Polarized retroreflective | MST-50-10 |
| | 100 × 100 mm | EAC | 5 | Retroreflective Polarized retroreflective | MST-100-5 |
| | 200 × 200 mm | EAC | 2 | Retroreflective Polarized retroreflective | MST-200-2 |


- Material: PMMA / PC / Acrylic (surface film / prism layer / adhesive layer) Ambient temperature: -35 to 65 °C (temperature for adhesion: 10 to 30 °C) Installation: Tape cutting (installation distance: \geq 20 mm)

■ Reflectance of MST Series

| Series | Sensing type | MST-50-10 | MST-100-5 | MST-200-2 |
|------------------------------|------------------------------|-----------|-----------|-----------|
| BTS | | 95% | 100% | 100% |
| ВМ | | 70% | 110% | 170% |
| BMS | Retroreflective | 90% | 120% | 190% |
| BEN | | 90% | 130% | 140% |
| ВХ | | 90% | 100% | 110% |
| BJ | | 40% | 60% | 100% |
| BJR | | 35% | 45% | 55% |
| ВЈХ | | 35% | 45% | 55% |
| ВН | | 60% | 80% | 140% |
| BEN | Polarized retroreflective | 70% | 90% | 120% |
| ВХ | retroreflective | 30% | 40% | 60% |
| BRQ | | 40% | 50% | 80% |
| BRQP (plastic material type) | | 40% | 80% | 85% |
| BRQPS (side sensing type) | | 25% | 30% | 35% |

Dimensions

(Unit: mm)




| Model | Α |
|-----------|-------|
| MST-50-10 | □ 50 |
| MST-100-5 | □ 100 |
| MST-200-2 | □ 200 |


■ Cautions during Installation

- Select a retroreflective tape that is suitable for the installation space and operating environment of the sensors.
- \bullet In general, a bigger size of retroreflective tape results in a longer sensing distance.
- \bullet Be sure to check the reflectance of the MST series for proper use.
- The reflectance may vary depending on the operating environment for the sensors.
- Before applying the tape, clean the adhesive side of the reflective tape with a dry
- \bullet Do not press or damage the surface of the retroreflective tape.
- \bullet Regularly clean the tape to maintain optimal performance, using only neutral detergents. Do not use chemical solvents.

Characteristic Curves: Through-beam Type


■ Sensing area





■ Emitter angle






Characteristic Curves: Retroreflective Type


■ Sensing area






■ Sensor angle





■ Reflector angle






Characteristic Curves: Polarized Retroreflective Type


■ Sensing area






■ Sensor angle





■ Reflector angle





Characteristic Curves: Diffuse Reflective Type

Sensing area



