TCD210046AC Autonics

Rectangular Photoelectric Sensors



BJX Series

PRODUCT MANUAL

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Features

- Long sensing distance with high quality lens
- : Through-beam type 30 m, diffuse reflective type 1 m, polarized retroreflective type 3 m (MS-2A)
- M.S.R. (Mirror Surface Rejection) function (Polarized retroreflective type)
- \bullet Compact size : W 11 \times H 32 \times L 20 mm
- Switch for selecting Light ON/Dark ON mode
- Built-in sensitivity adjustment adjuster
- $\bullet \ \ \text{Reverse power protection circuit, output short overcurrent protection circuit}$
- Mutual interference prevention function (except through-beam type)
- Excellent noise immunity and minimal influence from ambient light
- IP65 protection rating (IEC standard)

Safety Considerations

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

⚠ Warning Failure to follow instructions may result in serious injury or death.

- 01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g., nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
 Failure to follow this instruction may result in personal injury, economic loss or fire.
- 02. Do not use the unit in the place where flammable/explosive/corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present.

Failure to follow this instruction may result in explosion or fire.

03. Do not disassemble or modify the unit.

05. Check 'Connections' before wiring.

Failure to follow this instruction may result in fire.

- Do not connect, repair, or inspect the unit while connected to a power source.
 - Failure to follow this instruction may result in fire.

Failure to follow this instruction may result in fire.

⚠ Caution Failure to follow instructions may result in injury or product damage.

01. Use the unit within the rated specifications.

Failure to follow this instruction may result in fire or product damage.

02. Use a dry cloth to clean the unit, and do not use water or organic solvent. Failure to follow this instruction may result in fire.

Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, It may cause unexpected accidents.
- When connecting an inductive load such as DC relay or solenoid valve to the output, remove surge by using diodes or varistors.
- Use the product after 0.5 sec of the power input.
 When using a separate power supply for the sensor and load, supply power to the sensor first.
- The power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
- Wire as short as possible and keep it away from high voltage lines or power lines to prevent surge and inductive noise.
- When using switching mode power supply (SMPS), ground F.G. terminal and connect a condenser between 0V and F.G. terminal to remove noise.
- When using a sensor with a noise-generating equipment (e.g., switching regulator, inverter, and servo motor), ground F.G. terminal of the equipment.
- This unit may be used in the following environments.
- Indoors (in the environment condition rated in 'Specifications')
- Altitude max. 2,000 m
- Pollution degree 3
- Installation category II

Product Components

Sensing type	Through-beam	Polarized retroreflective	Diffuse reflective			
Product components	Product, instruction manual					
Reflector	=	MS-2A	-			
Adjustment screwdriver	×1	×1	×1			
Bracket A or B ⁰¹⁾	× 2	×1	× 1			
M3 bolt	× 4	× 2	× 2			

01) Cable type, cable connector type: Bracket A, connector type: Bracket B

Ordering Information

This is only for reference, the actual product does not support all combinations. For selecting the specified model, follow the Autonics website.

BJX 0 2 3 4 6

Sensing distance

Number: Sensing distance (unit: mm) Number+M: Sensing distance (unit: m)

Sensing type

T: Through-beam

P: Polarized retroreflective

D: Diffuse reflective

Power supply

D: 10 - 30 VDC==

Output

T: Solid state (transistor)

GConnection

No mark: Cable type C: Connector type

G Control output

No mark: NPN open collector output P: PNP open collector output

Sold Separately

- · Reflector: MS Series
- Bracket A. B.
- Retroreflective tape: MST Series M8 connector cable: CID(H)408-□, CLD(H)408-□

Cautions during Installation

- Be sure to install this product by following the usage environment, location, and specified ratings. Consider the listed conditions below
- Installation environment and background (reflected light)
- Sensing distance and sensing target
- Direction of target's movement
- Characteristic curves
- When installing multiple sensors closely, it may result in malfunction due to mutual interference.
- For installation, tighten the screw with a torque of 0.5 N m. Mount the brackets correctly to prevent the twisting of the sensor's optical axis.
- Do not impact with a hard object or bend the cable excessively. That could decrease the product's water resistance.
- Use this product after the test. Check whether the indicator works appropriately for the positions of the detectable object.

Through-beam	Retroreflective	Reflective
Emitter - Receiver: Install to face each other	Sensor - Reflector: At least 0.1 m apart, install to face each other (parallel with the sensing side of the unit)	Sensor - Sensing target: Install to face each other (parallel with the sensing side of the unit)


Setting Operation Mode

- · Be sure to set the mode before power-on.
- · Use the offered adjustment screwdriver. Do NOT turn with excessive force to prevent

L: Light ON mode	D: Dark ON mode
D L	_D C

Operation Timing Chart and Indicators


■ Light ON mode




- In Dark ON mode, the waveforms are reversed.
 Operation indicator and transistor output differ from the sensing method.


Connections

Cable type: Emitter



■ Cable type: Receiver, Polarized retroreflective, Diffuse reflective type





■ Connector type



Pin	Color	Function
1	Brown	+V
2	2 -	
3	Blue	0 V
4	Black	OUT


Connector pin ④ is N.C (not connected) terminal for the emitter.

Circuit

■ NPN open collector output

LOAD Max. 100 mA SCP

■ PNP open collector output



- OCP (over current protection), SCP (short circuit protection)
 If short-circuit the control output terminal or supply current over the rated specification, normal control signal is not output due to the protection circuit.


Sensitivity Adjustment

- Set the adjuster for stable Light ON area, minimizing the effect of the installation environment.
- Use the offered adjustment screwdriver. Do NOT turn with excessive force to prevent product damage
- The steps below are based on Light ON mode

STEP	Status	Description	
01	Received	^	Turn the adjuster from MIN ($-$) to MAX ($+$) sensitivity and check the position (A) where the operation indicator activates under the light ON area.
02	Interrupted	__B_	Turn the adjuster from (A) to MAX (+) and check the position (B) where the operation indicator activates under the light OFF area. If the operation indicator does NOT activate at the MAX (+, maximum sensitivity): MAX = (B).
03	-	A B	Set the adjuster at the mid position between (A) and (B) for optimal sensitivity.


Dimensions

- Unit: mm, For the detailed drawings, follow the Autonics website.
- This dimensions shows the cable type and connector type. Refer to the 'Specifications' for the core, wiring, and connector spec.




Α	Optical axis of emitter	D	Stability indicator (green)
В	Optical axis of receiver	E	Power indicator (red)
С	Operation indicator (yellow)		

■ Reflector (MS-2A)





■ Bracket A

■ Bracket B (BJP SERIES BRACKET B)









Specifications

Model	BJX∐-	ΓDT-□-□	J	BJX3M-PDT-□-□	BJX∐-DI	BJX□-DDT-□-□	
Sensing type	Through-beam			Polarized retroreflective	Diffuse re	Diffuse reflective	
Sensing distance	10 m	15 m	30 m 3 m ⁰¹⁾		100 mm	300 mm	1 m
Sensing target	Opaque materials		S	Opaque materials		Opaque materials, translucent materials	
Min. sensing target	≥ Ø 15 mm			≥ Ø 75 mm	-		
Hysteresis	-			-	≤ 20 % of sensing distance		stance
Response time	≤1 ms						
Light source	Red LED	Infrared	Red LED	Red LED	Infrared	Red LED	Red LED
Peak emission wavelength	660 nm	850 nm	660 nm	660 nm	850 nm	660 nm	660 nm
Sensitivity adjustment	YES (Ad	juster)		YES (Adjuster)	YES (Adjuster)		
Mutual interference prevention	- YES YES						
Operation mode	Light Of	N mode -	Dark ON i	mode selectable (Adjuster)			
Indicator	Operation	on indicat	or (yellow	v), stability indicator (green)	, power ind	icator (red)	04)
Approval	C€ E¥ €	91 2 us ER[C € ĽK • PU us ERI	C E E . S	∆us EAC	

- 01) Reflector (MS-2A)
 02) Non-glossy white paper 100 × 100 mm
 03) Non-glossy white paper 300 × 300 mm
 04) Only for the emitter

Unit weight (packaged)	Through-beam	Polarized retroreflective	Diffuse reflective					
Cable type	≈ 95 g (≈ 145 g)	≈ 50 g (≈ 115 g)	≈ 50 g (≈ 100 g)					
Connector type	\approx 12 g (\approx 65 g)	≈ 6 g (≈ 75 g)	\approx 6 g (\approx 60 g)					
Power supply	10-30 VDC== \pm 10 % (ripple P-P: \leq 10 %)							
Current consumption	It depends on the sensing	It depends on the sensing type						
Through-beam	Emitter: ≤ 20 mA, receiver	r: ≤ 20 mA						
Reflective	≤ 30 mA							
Control output	NPN open collector outpu	t / PNP open collector outp	out model					
Load voltage	≤ 30 VDC==							
Load current	≤ 100 mA							
Residual voltage	NPN: ≤ 1 VDC=, PNP: ≤ 2	2 VDC==						
Protection circuit	Reverse power protection	circuit, output short overcu	ırrent protection circuit					
Insulation resistance	≥ 20 MΩ (500 VDC= meg	≥ 20 MΩ (500 VDC== megger)						
Noise immunity	±240 VDC= the square w	ave noise (pulse width: 1 μ:	s) by the noise simulator					
Dielectric strength	Between the charging part	Between the charging part and the case: 1,000 VAC \sim 50/60 Hz for 1 min						
Vibration	1.5 mm double amplitude hours	at frequency of 10 to 55 Hz	in each X, Y, Z direction for 2					
Shock	500 m/s² (≈ 50 G) in each	X, Y, Z direction for 3 times						
Ambient illuminance (receiver)	Sunlight: ≤ 11,000 lx, inca	ndescent lamp: ≤ 3,000 lx						
Ambient temperature	-25 to 60 °C, storage: -40 to	70 °C (no freezing or cond	ensation) ⁰¹⁾					
Ambient humidity	35 to 85 %RH, storage: 35	to 85 %RH (no freezing or c	ondensation)					
Protection rating	IP65 (IEC standard)							
Connection	Cable type / Connector typ	oe model						
Cable spec.	Ø 4 mm, 3-wire (Emitter: 2	-wire), 2 m						
Wire spec.	AWG26 (0.52 mm, 20-core)	, insulator outer diameter:	Ø1mm					
Connector	M8 4-pin plug type							
Material	Case: PC, CAP: PC, sensing	Case: PC, CAP: PC, sensing part: PMMA						

⁰¹⁾ UL approved ambient temperature: 40 °C

Sold Separately: M8 Connector Cable

• For detailed information, refer to the 'M8/M12 Connector Cable' manual.


- For detailed information, refer to the MoyMiz connector capte mandat.						
Appearance	Power	Connector 1	Connector 2	Length	Feature	Model
******		M8 (Socket-	4	2 m	PVC	CID408-2
	DC	Female) 4-pin	4-wire	5 m	PVC	CID408-5
	M8 (Socket- Female)		4-wire	2 m	Oil resistant	CIDH408-2
	DC Female) 4-pin	4-WIIC	5 m	PVC	CIDH408-5	
III.	DC M8 (Socket- Female) 4-pin, L type		4-wire	2 m	- PVC	CLD408-2
				5 m		CLD408-5
	M8 (Socket-			2 m	Oil resistant	CLDH408-2
	DC Female) 4-pin, L type		4-wire	5 m	PVC	CLDH408-5

Sold Separately: Reflector MS Series

Appearance	Size (W × H)	Reflectance	Sensing type	Model
. 2000		Typical reflectivity	Retroreflective	MS-2
	40.5 × 60.5 mm	Typical reflectivity	Polarized retroreflective	MS-2A
		High reflectivity	Polarized retroreflective	MS-2S
	81.5 × 60.5 mm	Typical reflectivity	Retroreflective	MS-3
	81.5 × 60.5 mm	High reflectivity	Polarized retroreflective	MS-3S
29.3 × 38 mm		Typical reflectivity	Retroreflective	MS-4
	15.4 × 24 mm	Typical reflectivity	Retroreflective	MS-5
	13.7 × 23 mm	Typical reflectivity	Retroreflective	MS-6

- Material: PMMA / ABS (front part / rear part)
- Installation: Bolt mounting

Dimensions



■ Cautions during Installation

- Select a reflector size that is suitable for the installation space and operating environment of the sensors.
- In general, a bigger size of the reflector results in a longer sensing distance.
- Reflectors with high reflectivity increase the sensing distance compared to typical
- The reflectance may vary depending on the operating environment for the sensors.

Sold Separately: Retroreflective Tape MST Series

Appearance	Size (W × H)	Approval	Packaged unit	Sensing type	Model
	50 × 50 mm	EAC	10	Retroreflective Polarized retroreflective	MST-50-10
	100 × 100 mm	EAC	5	Retroreflective Polarized retroreflective	MST-100-5
	200 × 200 mm	EAC	2	Retroreflective Polarized retroreflective	MST-200-2


- Material: PMMA / PC / Acrylic (surface film / prism layer / adhesive layer) Ambient temperature: -35 to 65 °C (temperature for adhesion: 10 to 30 °C) Installation: Tape cutting (installation distance: \geq 20 mm)

Reflectance of MST Series

Series	Sensing type	MST-50-10	MST-100-5	MST-200-2
BTS		95%	100%	100%
ВМ		70%	110%	170%
BMS	Retroreflective	90%	120%	190%
BEN		90%	130%	140%
ВХ		90%	100%	110%
BJ		40%	60%	100%
BJR		35%	45%	55%
ВЈХ		35%	45%	55%
ВН		60%	80%	140%
BEN	Polarized retroreflective	70%	90%	120%
ВХ	retrorenective	30%	40%	60%
BRQ		40%	50%	80%
BRQP (plastic material type)		40%	80%	85%
BRQPS (side sensing type)		25%	30%	35%

Dimensions

(Unit: mm)




Model	Α
MST-50-10	□ 50
MST-100-5	□ 100
MST-200-2	□ 200


Cautions during Installation

- Select a retroreflective tape that is suitable for the installation space and operating environment of the sensors.
- In general, a bigger size of retroreflective tape results in a longer sensing distance.
- \bullet Be sure to check the reflectance of the MST series for proper use.
- The reflectance may vary depending on the operating environment for the sensors.
- Before applying the tape, clean the adhesive side of the reflective tape with a dry
- Do not press or damage the surface of the retroreflective tape.
- \bullet Regularly clean the tape to maintain optimal performance, using only neutral detergents. Do not use chemical solvents.

Characteristic Curves: Through-beam Type


■ Sensing area







Left ← Center → Right


• BJX10M-TDT-C-P







■ Emitter angle










Characteristic Curves: Polarized Retroreflective Type


■ Sensing area






■ Sensor angle





■ Reflector angle





Characteristic Curves: Diffuse Reflective Type

Sensing area

